

## STANDARD KIT INSTRUCTION MANUAL

**Limited Warranty:** Tub Refinishing, Inc. DBA Munro Products or Munro Bath Systems as follows; this warranty is in lieu of all other written or unwritten, expressed or implied warranties, and Tub Refinishing, Inc. DBA Munro Products or Munro Bath Systems expressly disclaims any warranty of merchantability or fitness for a particular purpose. The buyer assumes all risks whatsoever as to the use of the material. Keep away from children, animals, or persons that are sensitive to paint or fumes. Fumes can be harmful to humans and animals, and can also be flammable.

**Safety: A protective respirator can be worn if available. Use product with adequate ventilation. Always use rubber gloves.**

Tub Refinishing, Inc., DBA Munro Products or Munro Bath Systems, is not responsible for accidents or misuse of these products or parts and materials of this kit. Safety is in the hands of the user. If you are unsure about the use or safety of this product please return the unopened and unused kits to the supplier. Do not return goods without receiving a Return Materials Authorization (RMA) number from Munro Products. All returned goods are at the purchasers cost. Opened or used materials will be refused for credit. See all MSDS Sheets which are provided and are also available via our websites. <http://www.bathtubrefinishingkit.net>

**Suitability for use:** The user is responsible for establishing that these products are suitable for the user's application and that all requirements for meeting approvals, standards, codes, disposal, use and regulations of any kind are satisfied. Distributor denies any responsibility for establishing suitability of use; where, when, and how the materials from this kit are used. Read all information and instruction before use of this product. Use Caution!

**For Emergency: CHEMTREC® 1-800-424-9300**

*Tub Refinishing, Inc. DBA Munro Products, Munro Bath Systems, and BathWorks™. BathWorks™ is an exclusive trademark of this company.*

**Step 1:** Clear the tub of all personal items. Make sure there is positive air-flow as well as good ventilation on work areas at all time.

**CLEAN TUB THOROUGHLY!** Scrub bathtub with Ajax or Comet and steel wool, paying special attention to heavy soap area's. **NOTE:** ANY soap residue left behind will prevent bonding and cause failure.

**Step 2:** Using either a razor blade or sharp scraper remove the caulk around bathtub or walls. (optional)

**Step 3:** With a single edge razor blade scrape down the bathtub thoroughly keeping special attention to areas under the soap tray and drain area. Wipe all scrapings and foreign materials into a trash bag that should be next to you at all times for garbage. Never place tools or scraper on toilet seat covers, counter tops or linoleum floors.

While the bathtub or walls are still damp, sand them completely, using 120 or 220 grit sandpaper.

**Step 4:** Place glove or plastic bag over the tub spout and shower head to avoid water dripping on the bathtub. Using a blow dryer or strong wet-vac, blow water out of drain and wall areas. **NOTE:** Drying the complete surface especially at the drain is extremely important. ANY moisture while rolling will result in failure. When the surfaces are very dry, use blue painters tape to mask off walls around bathtub and tub drain. If refinishing both bathtub and walls, you will not need to tape off the wall area around the bathtub.

**Step 5:** Using a vacuum clean the full surface, removing all foreign materials from the bathtub or wall area. The bathtub or wall surface should be smooth and ready to be rolled. Any repairs, if needed, should be made to surface before using the vacuum.

**Caution:** In the following steps proper ventilation, gloves, and eye wear are recommended. Keep all refinishing kit materials and tools away from children, animals, and anyone sensitive to fumes. Some items in the kit are flammable and should be disposed of properly to city or town codes regulating used paint products. Use all paint products with caution.

**Step 6:** With a paper towel wipe the provided liquid primer on the complete bathtub and/or wall surface (if refinishing wall tile). Dispose of moist paper towel in closed plastic bag (to minimize fumes) when finished. Let the primer dry on the surface for 5 minutes.

**Step 7:** Thoroughly mix together the provided paint materials - Part A Color (Refinishing Paint) & Part B Hardener. Let mixed paint sit for 5 minutes. For non-slip application, pour approx. 1 oz of mixed paint material (part A & part B) into the included non-slip container. Mix thoroughly. Pour the non-slip mixture into the center of the tub. Using a 3 inch roller, roll an oval or rectangular shape in desired non-slip area. Let set for 10 minutes. You will have roughly 1 hour to use the product, before it becomes unusable. Dispose of unused paint immediately after use. Pour the stirred contents into a paint tray. **Note:** *Never dry roll - the roller should always have a good amount of paint on it.* Next, using a foam brush, dab-paint around all edges and areas where the roller will not fit. Then, using a tight 4 inch foam roller, roll the inside walls of the bathtub. Next, roll the bottom and up the curves of the bathtub. Remember to use a good amount of paint material while rolling...**this is very important.** Then roll the top edge of bathtub (leaving the top deck surface for last). Next, roll the front of the bathtub. Finally, roll the top deck surface.

A second coat can be applied right away following the same pattern. Be careful not to lean on wet surfaces. Dispose of all unused materials and garbage, as soon as you have completed the job. Keep away from flames, children, animals and those sensitive to paint fumes; obey all city or town codes for proper paint disposal.

**Step 8:** Waiting at least 45 minutes after you finish painting, carefully remove the tape. Pull tape at a 45 degree angle when removing. Let painted bathtub or walls dry 24 hours before using. Once dry, caulk bathtub and walls if needed. Allow caulk to dry, and rinse refinished fixture with warm water before using.

---

### **Warning:**

Painted bathtubs may become slippery when water and soap are used. You can use a Non-Slip Suction Mat, which can be purchased at Munro Products for \$69.00 & TubWorks® Cleaners are also available at Munro Products for \$24.00 for 8oz. containers; not including shipping. Munro Products to place order on line at [www.munroproducts.com](http://www.munroproducts.com). A good everyday cleaner available in most stores is Scrubbing-Bubbles®.

---

### **Supplies Included in Kit:**

Part A & B Paint (18oz. total), Liquid Primer 1oz, Directions, Safety Care Tips, **Note:** *Non-Slip Additive (2oz) included in special kits.*

---

**Supplies Needed by Customer:** Paint Tray & Rollers, Foam Brush, Steel Wool/Sandpaper, Tarp or Sheet, Blue Painters Tape, Paper Towels, Trash Bag, Rubber Gloves, Razor Blade Scraper, Shop Vac or Vacuum with Hose, Hair Dryer, & Proper Vent or Fan if no window is available. Other protective items you feel necessary under your situation. **If unsure, Don't Paint, and return kit unopened.**

### **For Recommended Tools & Supplies Visit:**

<http://www.bathtubrefinishingkit.net/Category/Accessories>